

Hardware architectures for Elliptic Curve Cryptography

Nele Mentens
nele.mentens@kuleuven.be

ECRYPT-CSA Workshop on Cryptographic Protocols for Small Devices

May 13, 2016, Vienna

Outline

- Introduction
- Datapath optimization
- Data storage optimization
- Control unit optimization
- Summary

- Introduction
 - Implementation platforms
 - ECC algorithms
 - ECC implementation
- Datapath optimization
- Data storage optimization
- Control unit optimization
- Summary

Cryptographic Protocols for Small Devices, May 13, 2016, Vienna


Introduction Implementation platforms

- microprocessor
- FPGA = Field-Programmable Gate Array
- ASIC = Application-Specific Integrated Circuit

Introduction

Implementation platforms – microprocessor

architecture



Example: AVR


The CPU is the heart of a microprocessor and contains a.o.:

- ALU (Arithmetic Logic Unit)
- register file
- program memory

Introduction


Implementation platforms – microprocessor

design flow



- The hardware architecture of a microprocessor is fixed
- The code describes what should be executed on the fixed hardware
- The instructions end up in the program memory


architecture



Basic components:

- CLB = Configurable Logic Block
 - CLBs consist of slices.
 - Slices consist of
 - Look-Up Tables (LUTs),
 - Multiplexers,
 - Flip-Flops (FFs),
 - Carry logic.
- SM = Switch Matrix
- IOB = Input/Output Block


basic content of a slice (excluding carry-logic)



Introduction

Implementation platforms – FPGA


basic principle of a switch matrix



Introduction

Implementation platforms – FPGA


1991: XC4000



Introduction

Implementation platforms – FPGA



1991: XC4000
 1998: Virtex



Introduction

Implementation platforms – FPGA



1991: XC4000
 1998: Virtex
 2002: Virtex-II Pro




Introduction

Implementation platforms – FPGA

- 1991: XC4000
- 1998: Virtex
- 2002: Virtex-II Pro
- 2004: Virtex-4





technology node:




Introduction

Implementation platforms – FPGA

- 1991: XC4000
- 1998: Virtex
- 2002: Virtex-II Pro
- 2004: Virtex-4
- 2006: Virtex-5





technology node:



Introduction

Implementation platforms – FPGA

- 1991: XC4000
- 1998: Virtex
- 2002: Virtex-II Pro
- 2004: Virtex-4
- 2006: Virtex-5
- 2009: Virtex-6





technology node:




Introduction

Implementation platforms – FPGA

- 1991: XC4000
- 1998: Virtex
- 2002: Virtex-II Pro
- 2004: Virtex-4
- 2006: Virtex-5
- 2009: Virtex-6
- 2010: Virtex-7





technology node:




Introduction

Implementation platforms – FPGA

- 1991: XC4000
- 1998: Virtex
- 2002: Virtex-II Pro
- 2004: Virtex-4
- 2006: Virtex-5
- 2009: Virtex-6
- 2010: Virtex-7
- 2013: Virtex UltraScale





technology node:




Introduction

Implementation platforms – FPGA

- 1991: XC4000
- 1998: Virtex
- 2002: Virtex-II Pro
- 2004: Virtex-4
- 2006: Virtex-5
- 2009: Virtex-6
- 2010: Virtex-7
- 2013: Virtex UltraScale
- 2015: Virtex UltraScale+




technology node:



Introduction

Implementation platforms – FPGA

design flow




- The hardware architecture of an FPGA is configurable
- The code describes the hardware that we need
- The bitstream ends up in the configuration memory
- The area is measured in terms of occupied LUTs, flip-flops, dedicated hardware blocks

Introduction

Implementation platforms – ASIC

architecture




Basic components:

- Standard cells from a standard cell library
 - Logic cells and sequential cells


Introduction

Implementation platforms – ASIC

design flow



- The hardware architecture of an ASIC is fixed
- The code describes the hardware that we need
- The GDSII file contains the physical information that goes to the foundry
- The area is measured in terms of the number of equivalent NAND gates (Gate Equivalent = GE)



Introduction

Implementation platforms – comparison

HW		HW-SW			SW
ASIC	FPGA	Domain specific	DSP	VLIW	General purpose
Area efficiency					
High					Low
Performance/Energy unit					
Low					High
Programmability					

Introduction

Implementation platforms – comparison

- FPGA advantages over ASIC
 - faster time-to-market
 - smaller Non-Recurring Engineering (NRE) cost
 - programmable in the field
- ASIC advantages over FPGA
 - lower cost for high volumes
 - better performance

Introduction

ECC algorithms

- Typical algorithm for point multiplication in Elliptic Curve Cryptography (ECC):
 - Evaluate one or more (original or recoded) bits of the scalar
 - Execute specific sequences of modular operations
 - Update intermediate variables

Introduction

ECC algorithms – example

Short Weierstrass curve: $y^2 = x^3 + a*x + b$

Modified Jacobian coordinates: $x = X/Z_2; y = Y/Z_3; T = a * Z^4$

$(X_3, Y_3, Z_3, T_3) = (X_1, Y_1, Z_1, T_1) + (X_2, Y_2, Z_2, T_2)$

$ZZ_1 = Z_1^2$

$ZZ_2 = Z_2^2$

$U_1 = X_1 * ZZ_2$

$U_2 = X_2 * ZZ_1$

$S_1 = Y_1 * Z_2 * ZZ_2$

$S_2 = Y_2 * Z_1 * ZZ_1$

$H = U_2 - U_1$

$I = (2 * H)^2$

$J = H * I$

$r = 2 * (S_2 - S_1)$

$V = U_1 * I$

$X^3 = r^2 - J - 2 * V$

$Y^3 = r * (V - X^3) - 2 * S_1 * J$

$Z_3 = ((Z_1 + Z_2)^2 - ZZ_1 - ZZ_2) * H$

$ZZ_3 = Z_3^2$

$T_3 = a * ZZ_3^2$

$(X_3, Y_3, Z_3, T_3) = [2](X_1, Y_1, Z_1, T_1)$

$XX = X_1^2$

$A = 2 * Y_1^2$

$AA = A^2$

$U = 2 * AA$

$S = (X_1 + A)^2 - XX - AA$

$M = 3 * XX + T_1$

$X_3 = M^2 - 2 * S$

$Y_3 = M * (S - X_3) - U$

$Z_3 = 2 * Y_1 * Z_1$

$T_3 = 2 * U * T_1$

Introduction

ECC algorithms – example

- Left-to-right binary point multiplication

in: $P \in G$, positive integer $n = (n_{l-1} \dots n_0)$, $n_{l-1} = 1$

out: $[n]P \in G$

$R \leftarrow P$

for $i = l-2$ to 0 do

$R \leftarrow [2]R$

if $n_i = 1$ then $R \leftarrow R + P$

$i \leftarrow i - 1$

Return R

Introduction

ECC implementation – microprocessor

- Typical algorithm for point multiplication in Elliptic Curve Cryptography (ECC):
 - Evaluate one or more (original or recoded) bits of the scalar → LSL, BREQ
 - Execute specific sequences of modular operations → ADD, ADC, SUB, SBC, MUL
 - Update intermediate variables


Introduction

ECC implementation – hardware architecture

- Typical algorithm for point multiplication in Elliptic Curve Cryptography (ECC):
 - Evaluate one or more (original or recoded) bits of the scalar → control unit + shift register + counter
 - Execute specific sequences of modular operations → control unit + datapath + data storage
 - Update intermediate variables → data storage

Introduction

ECC implementation – hardware architecture




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

18/45

Outline


- Introduction
- Datapath optimization
 - 256-bit addition
 - 256-bit multiplication
- Data storage optimization
- Control unit optimization
- Summary



Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

Datapath optimization

256-bit addition – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45

Datapath optimization

256-bit addition – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45

Datapath optimization

256-bit addition – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45

Datapath optimization

256-bit addition – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45


Datapath optimization

256-bit addition – microprocessor




Datapath optimization

256-bit addition – microprocessor



Datapath optimization

256-bit addition – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45

Datapath optimization

256-bit addition – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45

Datapath optimization

256-bit addition – microprocessor



Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

19/45

Datapath optimization

256-bit addition – hardware architecture

- most straightforward: ripple-carry adder
- parallel ... digit-serial ... bit-serial


Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

20/45

Datapath optimization

256-bit addition – hardware architecture


- most straightforward: ripple-carry adder
- **parallel** ... digit-serial ... bit-serial



Datapath optimization

256-bit addition – hardware architecture


- most straightforward: ripple-carry adder
- parallel ... **digit-serial** ... bit-serial



Datapath optimization

256-bit addition – hardware architecture

- most straightforward: ripple-carry adder
- parallel ... digit-serial ... **bit-serial**



Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

23/45

Datapath optimization

256-bit addition – hardware architecture

- most straightforward: ripple-carry adder
- parallel ... **digit-serial** ... **bit-serial**
 - less logic for adding digits/bits
 - overhead in control logic, counter, input and output shift registers, carry register


Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

24/45

Datapath optimization

256-bit addition – hardware architecture

FPGA: fast carry-chains for ripple-carry addition



(just write $s \leq a + b$ in VHDL)

(source: <http://www.fpga4fun.com>)


Datapath optimization

256-bit addition – hardware architecture

- ASIC:
 - ripple-carry adder using HA and FA standard cells
 - faster architectures:
 - carry look-ahead, carry-select, conditional sum,...

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

27/45

Datapath optimization

256-bit multiplication – microprocessor



Datapath optimization


256-bit multiplication – microprocessor

- Optimization:
 - rely on the compiler
 - do low-level programming (assembly)

Datapath optimization

256-bit multiplication – hardware architecture

most straightforward: carry-save multiplier



Cryptographic Protocols for Small Devices, May 13, 2016, Vienna


29/45

Datapath optimization

256-bit multiplication – hardware architecture

FPGA: dedicated multipliers in the DSP slices

(just write $p \leftarrow a * b$ in VHDL)



(source: <http://www.eetimes.com>)


Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

30/45

Datapath optimization

256-bit multiplication – hardware architecture


- ASIC
 - standard cells for the design of multipliers
 - faster architectures:
 - carry-save multiplier, Booth multiplier,...



Cryptographic Protocols for Small Devices, May 13, 2016, Vienna


Outline

- Introduction
- Datapath optimization
- Data storage optimization
 - Microprocessor
 - Memory in hardware
- Control unit optimization
- Summary



Data storage optimization Microprocessor

- Comply to the data memory available on the processor




Data storage optimization Memory in hardware

- Flip-flop
 - bit storage on a clock edge
- Embedded SRAM
 - matrix structure
 - row-based read and write


Data storage optimization

Memory in hardware – flip-flops

- Fixed area per bit:
 - FPGA: basic element




- ASIC: standard cell (5.5 – 12 GE)
 - Example: UltraSparc flip-flop



Data storage optimization

Memory in hardware – flip-flops


- Register file: overhead for the output selection and the address decoder in a register file



Data storage optimization

Memory in hardware – flip-flops

- Optimizations:
 - Scan flip-flop: standard cell, designed for scan-chain testing, combining a flip-flop and a multiplexer
 - Can also be used in normal operation mode in ASICs
 - Flip-flop + multiplexer: 8 GE (open source NanGate library)
 - Scan flip-flop: 7.667 GE (open source NanGate library)




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

36/45

Data storage optimization

Memory in hardware – flip-flops

- Optimizations:
 - Shift register: to avoid the address decoder
 - For both FPGA and ASIC, but not always possible
 - FPGAs have dedicated, optimized shift registers with parameterizable output selection




Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

37/45

Data storage optimization

Memory in hardware – embedded RAM

- Fixed area per bit: ~ 1.5 GE




(source: <https://commons.wikimedia.org>)

Data storage optimization

Memory in hardware – embedded RAM

- Overhead for the address decoder
- Additional overhead for drivers and sense amplifiers per column




Data storage optimization

Memory in hardware – embedded RAM

- FPGA: embedded RAM blocks (BRAM = Block RAM)
 - Example Xilinx Spartan-6:
 - Configurable 8 Kb blocks:
 - 8k x 1, 4k x 2, 2k x 4, 1k x 8, 512 x 16, 256 x 32
 - Single-port, dual-port
- ASIC: embedded RAM using memory compilers
 - Rule of thumb: use flip-flops for memories smaller than 8x8

Outline


- Introduction
- Datapath optimization
- Data storage optimization
- Control unit optimization
 - Microprocessor
 - Control in hardware
- Summary



Control unit optimization

Microprocessor


- Comply to the program memory available on the processor
- Rely on the compiler or do low-level programming (assembly)



Control unit optimization


Control in hardware – Finite State Machine (FSM)

- An FSM runs through a finite number of states
- The next state is determined based on the inputs
 - “start” in the example
 - the key bits in a scalar multiplication FSM
- The output is determined by the state (and sometimes by the inputs)



Control unit optimization


Control in hardware – FSM in logic + flip-flops



- FPGA: using LUTs and flip-flops
- ASIC: using logic standard cells and flip-flop standard cells

Control unit optimization

Control in hardware – microcode approach



- FPGA: use BRAM for the instruction memory
- ASIC: use embedded RAM for the instruction memory if the size is big enough

- Introduction
- Datapath optimization
- Data storage optimization
- Control unit optimization
- Summary

Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

- Datapath optimization
 - FPGA: maximize the use of DSP slices
 - ASIC: use optimized architectures
- Data storage optimization
 - FPGA: maximize the use of BRAM
 - ASIC: use flip-flops or embedded RAM
 - depending on the size of the memory
- Control unit optimization
 - FPGA: use FSMs in logic + FFs or microcode approach (instructions in BRAM)
 - depending on the size of the FSM
 - ASIC: use FSMs in logic + FFs or microcode approach
 - depending on the size of the FSM

Cryptographic Protocols for Small Devices, May 13, 2016, Vienna

45/45